




SETUP GUIDE



Deck	Truck	80mm Kegel	75mm In Heat	75mm Durian	73mm The Cage	72.5mm Moronga	70mm 4President	70mm Stimulus	69mm The Kilmer	66mm The Keanu	65mm Fat Free	62mm Skiffs	58mm Onsens
	Paris 180mm, 50"	1/8" riser	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad
	Caliber 10", 50"		1/4" riser	1/8" riser	1/8" riser	1/8" riser	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad
	Bear 180mm, 52"	1/8" riser	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad
	Paris 180mm, 50"	1/8" riser	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad
	Paris 180mm, 43"	Bushing change	1/4" riser	1/8" riser	1/8" riser	1/8" riser	1/8" riser	1/8" riser	1/8" riser	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad
	Caliber 10", 50"	1/8" riser	1/8" riser	1/8" riser	1/8" riser	1/8" riser	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad
	Caliber 10", 44"	1/4" riser	1/4" riser	1/4" riser	1/4" riser	1/4" riser	1/4" riser	1/8" riser	1/8" riser	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad
	Bear 180mm, 52"	1/8" riser	1/8" riser	1/8" riser	1/8" riser	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad
	Ronin 180mm, 42.5"	Bushing change	Bushing change	1/4" riser	1/4" riser	1/4" riser	1/4" riser	1/4" riser	1/4" riser	1/8" riser	1/8" riser	1/16" shockpad	1/16" shockpad
	Paris 180mm, 50"	Bushing change	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad		
	Bear 180mm, 52"	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad		
	Paris 150mm, 50" (inner WB)	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed
	Bear 180mm, 52" (inner WB)	1/8" riser	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed
	Caliber 10", 50" (outer WB)	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed
	Paris 180mm, 50"	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed
	Paris 180mm, 50"	Bushing change	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad		
	Bear 180mm, 52"	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad		
	Independent 149-Hard Bushings									1/4" riser	1/4" riser		
	Independent 159- Hard Bushings											1/4" riser	1/16" shockpad
	Paris 150mm, 50"						1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	
	Carver CX.4 / C2.4						1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	
	Independent 159- Hard Bushings									1/4" riser	1/4" riser		
	Independent 169-Hard Bushings											1/4" riser	1/16" shockpad
	Paris 180mm, 50" (outer WB)		1/4" riser	1/4" riser	1/8" riser	1/8" riser	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad
	Paris 180mm, 43" (outer WB)						1/4" riser	1/4" riser	1/4" riser	1/8" riser	1/8" riser	1/8" riser	1/16" shockpad
	Caliber 10", 50" (outer WB)						1/4" riser	1/4" riser	1/4" riser	1/8" riser	1/8" riser	1/16" shockpad	1/16" shockpad
	Caliber 10", 44" (outer WB)						1/4" riser	1/4" riser	1/4" riser	1/8" riser	1/8" riser	1/16" shockpad	1/16" shockpad
	Bear 180mm, 52" (outer WB)		1/8" riser	1/8" riser	1/8" riser	1/8" riser	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad
	Independent 159 (inner WB)									1/4" riser	1/4" riser		
	Paris 150mm, 50"	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	
	Paris 180mm, 50"	Bushing change	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad
	Carver CX.4 / C2.4						1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	
	Paris 180mm, 50"	Bushing change	Bushing change	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	
	Caliber 10", 50"								1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	
	Bear 180mm, 52"	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	
	Paris 180mm, 50" (inner WB)	1/8" riser	1/8" riser	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	
	Paris 180mm, 43" (inner WB)	Bushing change	1/4" riser	1/4" riser	1/4" riser	1/4" riser	1/4" riser	1/4" riser	1/4" riser	1/8" riser	1/8" riser	1/8" riser	
	Caliber 10", 50" (outer WB)	1/8" riser	1/8" riser	1/8" riser	1/8" riser	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	
	Caliber 10", 44" (outer WB)		1/4" riser	1/4" riser	1/4" riser	1/4" riser	1/8" riser	1/8" riser	1/8" riser	1/16" shockpad	1/16" shockpad	1/16" shockpad	
	Bear 180mm, 52" (either WB)	1/8" riser	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	1/16" shockpad	
	Ronin 180mm, 42.5" (inner WB)	Bushing change	1/4" riser	1/4" riser	1/4" riser	1/4" riser	1/4" riser	1/4" riser	1/4" riser	1/8" riser	1/8" riser	1/16" shockpad	
	Paris 180mm, 50"	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed
	Caliber 10", 50"	1/8" riser	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed
	Bear 180mm, 52"	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed	No riser needed

KEY: No riser needed | 1/16" shockpad | 1/8" riser | 1/4" riser | Bushing change | No recommended

Note: Recommendations are based on an "average" rider weight of 150-200 lbs, stock bushings, and neutral kingpin tightness (no slop or excessive bushing preload). Compatibility and wheel clearance may vary for heavier riders or extremely loose truck settings. Always check for wheelbite and make any necessary adjustments before riding a new or modified setup!